

FIVE STAR PROTECTION

LOCK
 **and GO**
FLOORING



Special Introduction Pricing
\$25.00 per roll till July 1, 2017

Natural Cork Underlayment

PRODUCT SPECIFICATIONS

- Item #: LNGCORK (100 sf roll)
- 2mm Thick
- Density 200-220 kgs/m³
- Made from Natural Cork
- Install a .06 mm Polyethylene Film Moisture Barrier when needed
- All Natural Breathable underlayment for use over dry crawlspaces.
- All Natural Sound Reduction reduces reflective sound noise and through the floor sound transmission
- For use with raised wood-frame structures without HVAC control underneath the areas where underlayment is used.
- For use with Floating Laminate, LVT and WPC products not for use with Loose Lay material.

Installation instructions on back

Distributed By:
Crescent Hardwood Supply, Inc.

1101 Sams Avenue
Harahan, LA 70123
504-309-6950

www.LockandGoFlooring.com

Natural Cork Installation Instructions:

It important to follow the installation, first step is to determine is type subfloor installation concrete or wood. Furthermore note special instructions when using with floating vinyl floors.

Wood Subfloor

First walk the area where the floors will be installed to determine if subfloor is loose or secure. Take moisture reading on the top and bottom side of the subfloor. Then check the flooring manufacturer's guidelines to see if they are within tolerance. If the subfloor is uneven or not secure correct any deficiencies found. Surfaces must be clean, dry and smooth; free of voids, projections, loose materials, oil, grease, sealers, and all other surface contaminants. Maximum floor variation is 1/8" in 10 feet. Note floors not properly flattened can cause damage to locking system and cause squeaks in the floor system. In a raised frame crawl space system visqueen vapor barrier goes on the ground cover under the house with water draining away from the house. 15# felt paper butting the row can be place under the cork with laminate and wood flooring. ***Never put your vapor barrier on top the wood subfloor it will damage the subfloor over time.***

Concrete Subfloor

Surfaces must be clean, dry and smooth; free of voids, projections, loose materials, oil, grease, sealers, and all other surface contaminants. Maximum floor variation is 1/8" in 10 feet. Note floors not properly flattened can cause damage to locking system and cause squeaks in the floor system.

Special Note when Installing Floating Vinyl or WPC Vinyl Flooring over Cork

Unroll cork at least 24 hour in advance to acclimate before the installation and cut to desired length. Lay cork loosely over area to be installed. Both ends of the roll must curl down towards the subfloor. If the ends are curl up, flip material over. Butt cork directly against the subfloor. Pull the loose laid material back to at least half the length of the roll. Using a 3/16" x 5/32" v-notch trowel, apply a flooring adhesive to the subfloor. Gently, return the pulled back material and roll in both directions with a 100 lb. roller. Repeat this procedure for the other half of the roll. Proceed to cover the entire floor making sure all joints are butted together tightly It is important on these thin vinyl locking system to have no bubbles are voids when applying the cork in the adhesive. Never apply a double layer cork.

Installation of Natural Cork Underlayment

After doing required moisture testing for your floor; unpack the cork underlayment at least 24 hour in advance to acclimate before the installation. Unroll the cork underlayment and cut to desired length and install directly over the entire floor pulled 1 1/4" to the walls with crown of the rolled materials up, removing all trapped air. After completion, the underlayment should cover the entire flooring area without gaps and with joints butted tight and preferably taped. Underlayment rolls can be just laid on subfloor when customer installs floating floors. It is recommended when gluing hardwood floors to glue the cork using a 3/16" x 5/32" v-notch trowel, with a flooring adhesive to the subfloor. Then installs glue-down hardwood floors (or similar product) over the underlayment with the notch trowel recommended by the glue manufacturer.

Floor Installation

Follow manufactures recommend installation instructions and recommendations.