



Moisture & Sound Underlayment

Product Specifications

- ~ Item #: LNGPU1
- ~ 100 square foot rolls
- ~ 2mm thick
- ~ Dense Blended Synthetic Fibers
- ~ .06 mm Polyethylene Film Moisture Barrier
- ~ Self-sealing Overlap Tape Strip Attached
- ~ Excellent Sound Reduction
- ~ For use with Laminate and Engineered Wood Flooring
- ~ Remove polyethylene film when used on raised wood- frame homes
- ~ Not for use in raised wood-frame structures without HVAC control underneath the areas where underlayment is used.
- ~ Not for use with Floating LVT

Installation:

- 1) Roll out Ultimate Underlayment on a Dry, Clean, and Flat Subfloor
- 2) Put the tape side to the wall, then roll underlayment over subfloor with vapor barrier facing up. Remove visqueen when used on wood subfloors.
- 3) Roll the foam out with the next row butting the foam to the previous row.
- 4) Remove tape strip and place the overlapping poly film to the tape strip creating a moisture barrier. Any tears in the visqueen should be taped repairing the barrier.
- 5) After all underlayment is laid, Install your floor according to the manufacturers' instructions.

Distributed By:



Phone: 504-309-6950 Fax: 504-309-6949

www.lockandgoflooring.com